

The LSR should be mounted flush against the exhaust shaft using three or four rivets or self-tapping screws. It is critical for clothes dryer exhaust shafts that the screws or rivets be installed from the inside of the shaft so that their ends do not protrude into the main shaft.

When using four rivets or self-tapping screws use locations A and B. B location should be no higher than the top of the vent connection.

When using three rivets or self-tapping screws use locations A and C.

